



SHEET METAL RIB CAP

FASTENERS

APPLY FAST FLASH APPROXIMATELY 2 INCHES (5 CM) WIDE BEYOND THE SIZE OF THE RIDGE CAP. INSTALL THE RIDGE CAP INTO THE WET COATING. STITCH SCREW THE RIDGE CAP ONTO THE METAL ROOF PANEL. IMMEDIATELY INSTALL A SECOND COAT OF FAST FLASH ONTO THE RIDGE CAP AT LEAST 2" BEYOND THE REPAIR.

NOTE: RIB CAPS ARE REQUIRED OVER BROKEN RIBS; AFTER INSTALLED, SEAL THE RIB CAP PERIMETER AND FASTENERS WITH FAST FLASH.

# RIB CAP



Phone: 702-966-9961 | [www.EverRoof.com](http://www.EverRoof.com)

The information contained herein is for reference only, and is designed for users having the requisite knowledge, skill, and experience to determine suitability of a product's use and application. Conditions affecting application and use will vary, and users are required to make their own independent determination regarding suitability. No warranties or representations of any kind, whether express or implied, including warranties of merchantability or fitness for a particular purpose are made. EVERROOF assumes no obligation or liability with regard to the descriptions, designs, or information provided herein. All information is designed and intended to be reviewed in conjunction with other detailed specifications, application guidelines, technical bulletins, technical data sheets, and low slope restoration system specifications. rev. 4/26/2016 ©EVERROOF